

**YAMAHA G22 Safari Bar  
Installation Instructions  
Black- Part# 6276  
Gunmetal- Part# 7079  
Stainless- Part# 6276-S**



**Parts List**

*Safari-1*

*3/8 x 3 Bolts-2*

*3/8 Flatwashers-2*

*3/8 Locknuts-2*



 *Always wear appropriate  
eye protection!*

1. Remove the front bumper from the cart as shown in Figure 1. Save the two bolts for installing the safari bar.
2. Using the stock top bumper bolts, bolt the safari bar to the stock bumper mounting location.
3. Using the supplied bolts, washers, & locknuts loosely install the safari bar to the front frame holes.
4. Securely tighten all bolts.



866-405-2537

[www.jakesliftkits.com](http://www.jakesliftkits.com)