

# QUICK REFERENCE

## Status Light:

The status light will flash red and green when powered on, if a fault is detected and during pre-charge diagnostics.

It may take up to 90 seconds for the charger to fully analyze battery capacity and temperature readings prior to charging.

## Charger States: *(Battery Capacity)*



### **Power/Fault/Pre-charge diagnostics:**

Flashes *red* 1 second, *green* 1 second

*(Please refer to instruction manual for possible fault reasons)*



### **Trickle Charging: (0% - 20%)**

*Red* flashing on 1 second, off 3 seconds



### **Low Battery Charging: (20% - 80%)**

*Red* flashing on 1 second, off 1 second



### **Normal Charging: (80% - 99%)**

*Yellow* flashing on 1 second, off 1 second



### **Fully Charged: (100%)**

Solid *green* light

**DON'T FORGET** to regularly check your battery water levels. Battery water levels should be checked before and after charging. Doing so will prolong the life of your batteries.