


E-Z-GO Long Travel Lift Kit
2001.5 & Newer Electric TXT
Installation Instructions
Part# 6221
U.S.PAT. 7581740



ITEM	QTY
A. JAKES SUB-FRAME	1
B. TOP FRAME SUPPORT	1
C. STAINLESS STEEL FRONT BUMPER	1
D. 3/8" X 1" NUTS & BOLTS FOR FRAME SUPPORT	6
E. 17" CHROME ADJUSTABLE COIL OVER SHOCKS	2
F. PASSENGER SIDE TOP A-ARM	1
G. DRIVER SIDE TOP A-ARM	1
H. PASSENGER SIDE BOTTOM A-ARM	1
I. DRIVER SIDE BOTTOM A-ARM	1
J. 7/16" X 3 1/2" BOLTS NUTS & SPACERS	2 ea
K. STEERING EXTENSION	1
L. STEERING BOX	1
M. 1/2" X 6" KINGPIN BOLT AND NUT	2 ea
N. 7/16" X 1 1/4" BOLTS AND NUTS	8 ea
O. 7/16" X 5 1/2" BOLTS AND NUTS FOR SHOCKS	2 ea
P. WARNING LABEL	1
Q. REAR LIFT MOUNTS	2 ea
R. NUTS AND BOLTS FOR REAR LIFT	8 ea
S. PASSENGER SIDE SPINDLE	1
T. DRIVER SIDE SPINDLE	1
U. 5/16" X 4" BOLTS & NUTS FOR STEERING BOX	3 ea (NOT PICTURED)
V. 1/4" X 1 1/2" BOLT & LOCKNUT FOR STEERING EXT.	1 ea (NOT PICTURED)
W. 3/8" X 1 1/4" BOLT & LOCKNUT FOR STEERING EXT.	1 ea (NOT PICTURED)
X. REAR SHOCK MOUNTS	2
Z. 3/8" X 1 1/4" ALLEN BUTTON HEAD BOLT	1 (NOT PICTURED)
Z-1 SHOCK SUPPORTS W/ 7/16 X 1 1/4 BOLTS & LOCKNUTS	2 ea (NOT PICTURED)

 *Always wear appropriate eye protection!*

FRONT ASSEMBLY

1. Place the cart on jack stands.
2. Remove front tires and wheels.
3. Remove the front cowl.
4. Completely disassemble the front of the golf cart as shown in Figure 1. Save the stock leaf spring bolts & mounting plates, & hubs for reinstallation.
5. Mount Jakes sub-frame (ITEM A) to the stock leaf spring mounting location using the stock nuts, bolts and mounting plates as shown in Figure 2.




Figure 1

6. Line Jake's top frame support holes up with the outside holes on the frame. Using Jakes top frame support (ITEM B) as a guide, mark frame using the middle hole as a guide. Drill a 3/8" hole in the frame as shown in Figure 3 and drill the remaining 2 holes to 3/8".




Figure 3

7. Mount Jakes top frame support (ITEM B) to the frame and Jakes sub-frame (ITEM A) using the supplied nuts and bolts (ITEM D) as shown in Figure 4. **NOTE: Use the allen button head bolt (ITEM Z) on the third hole from the left on the bottom with the nut towards the front of the cart for steering clearance.**

Figure 4

8. Mount Jakes coil over shocks to the top frame support (ITEM B) with the appropriate hardware (ITEM J) and shock supports (ITEM Z-1) as shown in Figure 5. **NOTE: The larger end of the shock spacer goes against the frame support.** **NOTE: There are several locations to mount your shocks. Outside holes are for a stiffer ride and inside holes are for a softer ride. The top hole on the outside is for a 4" lift. Each hole below lifts the cart an additional 1".**



9. Mount Jake's bottom A-Arms (ITEMS H & I) to the sub-frame using the appropriate hardware (ITEM N) as shown in Figure 6. **NOTE: A-Arms are marked P-Top, P-Bottom, D-Top, D-Bottom. P=passenger side, D=Driver side.**
10. Mount the shocks to the bottom A-Arms using the appropriate hardware (ITEM O) as shown in Figure 6.
11. Mount Jake's top A-Arms (ITEMS F & G) to the sub-frame using the appropriate hardware (ITEM N) as shown in Figure 7.




FIGURE 5

FRONT ASSEMBLY CONTINUED

12. Attach Jake's spindles (ITEMS S & T) to the A-Arms using the supplied nuts & bolts (ITEM M).
13. Mount Jake's steering extension (ITEM K) to Jake's steering box (ITEM L) using the supplied nut and bolt (ITEM W).
14. Loosely mount Jake's steering extension to the stock steering column using the supplied nut and bolt (ITEM V). Loosely mount Jake's steering box to the top frame support (ITEM B). **SECURELY TIGHTEN ALL BOLTS. NOTE: WASHERS MUST GO BETWEEN SUB-FRAME & STEERING BOX. SECURELY TIGHTEN ALL BOLTS AS SHOWN IN FIGURE 10.**
15. Attach the tie rod ends to the spindles as shown in Figure 8.
16. Install the stock hubs to the spindles using the stock hardware.
17. Install Jake's recommended 23x10.5x12 or 22x11x10 offset wheels/tires. **NOTE: Your stock wheels/tires will not work.**
18. Adjust toe-in. Proper toe-in should be approximately 1/8" in.
19. Mount Jake's stainless steel front bumper (ITEM C) to the sub-frame using the supplied nuts and bolts as shown in Figure 9.
20. **SECURELY TIGHTEN ALL NUTS AND BOLTS.**






Figure 9




Figure 10



REAR INSTALLATION

1. Jack up the rear end of the cart and place jack stands on the frame in front of the springs. You will be installing larger wheels and tires so raise the cart high enough to accommodate the additional height. Place a car jack under the rear-end housing.
2. Remove the wheels and tires.
3. Unbolt the bottom of the shocks. Clean and lubricate these bolts for later use.
4. Unbolt the rear leaf springs from under the rear end. Save the stock hardware for reinstallation. Lower the rear-end using the car jack.
5. Place JAKES rear risers (Item Q) on top of the axle. **NOTE:** Parts are universal. There is no left or right side.
6. Place the leaf springs on top of the risers. Loosely mount the front of the leaf springs to the stock leaf spring mount using the stock hardware.
7. Place JAKES rear shock plates (Item X) on top of the leaf springs with the shock mount holes facing the rear of the cart and towards the center. Using the supplied nuts & bolts (Item R) mount the shock plates to the rear risers with the leaf springs sandwiched in between them. The bolts go through the new shock mount, rear risers, and stock shock mount. Make sure you tighten these bolts evenly.
8. Bolt the rear of the leaf springs to the stock rear leaf spring mount using the stock hardware. Attach the bottom of the shocks to JAKES new shock mounts on the rear shock plates using the stock nuts and bolts.
9. Use wire ties to fasten the brake cable to either the underside of the springs or the frame.
10. Double check all nuts and bolts for tightness.
11. Install JAKES recommended wheel and tire size 22 x 11 x 10 wheels and tires with a 3 x 5" offset for maximum performance.
12. Included is a warning label (Item P) which is to be placed on the steering column or another visible area and is to be read by all operators.



Indemnification And Insurance Agreement

High Performance Enhancement Kit purchaser assumes sole and entire responsibility for, and shall indemnify and save harmless Nivel LLC, from any and all claim, liability, responsibility, and persons or property that may be sustained in connection with the use of any product before or after purchase, including but not limited to high performance enhancement lift kits. The High Performance Enhancement Kit purchaser also shall indemnify Nivel LLC harmless with respect to any and all liability that may be incurred.

Golf Cars are recommended for use only by those aged 16 and older. Golf Cars can be especially hazardous to operate. Always remember that riding and alcohol/drugs don't mix. Never ride on public roads. Never carry more than two passengers (except shuttles and trams). Never engage in stunt driving. Avoid excessive speeds and be particularly careful on difficult terrain. Nivel LLC reserves the right, at any time, to discontinue or change specifications, prices, designs, features, models, or equipment without notice and without incurring any obligation.



866-405-2537

www.jakesliftkits.com

© Copyright Nivel LLC
All Rights Reserved